

D108 Boot 2

User Manual

Contents

Basic Information.....	3
<i>Warnings</i>	<i>3</i>
Before Using	4
<i>SIM</i>	<i>4</i>
<i>Phone Unlock.....</i>	<i>4</i>
<i>SIM Unlock</i>	<i>4</i>
Function menu Introduction	5
<i>File manager.....</i>	<i>5</i>
<i>Contacts</i>	<i>5</i>
<i>Fun</i>	<i>6</i>
Games.....	6
<i>Call logs</i>	<i>6</i>
Call history	6
Call settings	7
<i>Messages</i>	<i>8</i>
Write message	8
Inbox	8
Drafts.....	8
Outbox.....	8
Sent messages.....	8
Message settings.....	9
<i>Multimedia</i>	<i>9</i>
Camera	9
Image viewer.....	9
Video recorder.....	10
Video player	10
Audio player	10
Sound recorder	10
FM radio.....	10

<i>Organizer</i>	11
Calendar	11
Calculator	11
Alarm.....	11
<i>Settings</i>	11
User Profiles	11
Phone settings.....	12
Security settings	13
Network settings.....	13
Restore settings	14
<i>Internet</i>	14
Internet service	14
SKT	14
Facebook	15
Twitter	15

Basic Information

Warnings

Not following these simple guidelines may be dangerous or illegal.
Read the complete user guide for further information.

TURN ON SAFELY

Do not turn on the phone when wireless phone is prohibited or when it may cause interference or danger.

ROAD SAFETY

Obey all road safety laws. Always use both of your hands to operate the vehicle while driving.

INTERFERENCE

All wireless phones may be sensitive to interference, which may affect performance.

TURN OFF IN HOSPITALS

Follow all restrictions. Turn off the phone near medical equipment.

TURN OFF ON AIRCRAFTS

Follow all restrictions. Wireless devices can cause interference on aircrafts.

TURN OFF WHEN REFUELING

Do not use the phone at/near refueling stations. Do not use near fuel or chemicals.

USE SENSIBLY

Only qualified personnel may install or repair this product.

ENHANCEMENTS AND BATTERIES

Use only appropriate enhancements and batteries. Do not connect incompatible products.

WATER-RESISTANCE

Your phone is not water-resistant. Keep it dry.

BACKUP COPIES

Remember to make back-up copies or keep a written record of all important information stored in your phone.

CONNECTING TO OTHER DEVICES

When connecting to any external device, read its user guide for detailed safety instructions. Do not connect with incompatible products.

Before Using

SIM

You must insert the SIM card before you use the phone. SIM card is provide by the network provider.

Warning: Be sure power off your phone before you remove the SIM card. There is absolutely prohibited that remove the SIM card when the phone is connected with the external power supply, otherwise the SIM card and mobile phone may be damaged.

Phone Unlock

In order to prevent illegal use, your phone can set the phone lock password protected. When you selected this function, you must enter the phone lock password to unlock the phone into the normal use state.

Enter the phone lock password then press the LSK to confirm.

SIM Unlock

In order to prevent illegal use of your SIM with PIN (Personal Identification Number) password encryption protection. Use this function, if you have set the PIN password protection, every time you must enter the PIN password at boot time, so that you can unlock the SIM card and phone for the normal usage. Enter the PIN password, press the LSK to confirm. For example, if the PIN is set to 1234, then the following input: 1234.If there consecutive incorrect, your SIM will be network locked, the phone will ask for PUK password.

Function menu Introduction

File manager

Into the File manager menu, the menu display **Phone** and **Memory card**. Root directory, select "**Phone**", press the **LSK** to enter "**Options**" can be as follows:

- **Open** Open the root directory lists the directories and files.
- **Format** Format the memory card
(All the data inside the card would be delete)

Root directory, select "**Memory Card**", press the **LSK** to enter "**Options**" can be as follows:

- Open** Open the root directory lists the directories and files.
- Format** Format the memory card, this action will remove all current flash memory data.
- Details** To view the information of the file/ folder, such as Name, Total size, free size.

You can play the music or video files, view Photo, copy/move/delete files, rename files and so on. You can send the file through BT.

Contacts

You can use the phonebook to store records, can store the following: name and phone number. In the phonebook list, select a record, to make a call when you press the dial keys. Select a record in the phonebook, you can do the following:

- View** View the contact details or edit record.
- Send text message** Send text message to this number.
- Call** Make a call to the number.
- Edit** Can edit and save record.
- Delete** Delete the record.
- Copy** Copy the current record to Phone/SIM.
- Add to Blacklist** Add the number to call blacklist number.

-Phonebook settings:

- Preferred storage** Select SIM1, SIM2, Phone and All to switch, and phonebook list will change accordingly.
- Speed dial** Open speed dial. If you long press number keys on the dialing interface, you can call up.
- Extra numbers** You can set fixed dialing numbers.
- Memory status** View the usage and total Phonebook capacity.
- Copy contacts** To copy the contacts from SIM to phone/SIM and from phone to SIM.
- Move contacts** To move the contacts from SIM to phone/SIM and from phone to SIM.
- Delete all contacts** To delete all the contacts of SIM and phone.

Fun

Games

Snake

Games settings: You can set BGM,sound effect and volume.

Call logs

Call history

Missed calls

Enter the missed calls menu, will display the missed calls list. Select missed call records, press the Options key:

- View** View the details.
- Call** Call the record number.
- Send text message** Send text message to record number.
- Save to Phonebook** Save the number to the phone or SIM card.
- Add to Blacklist** Save the number to call blacklist number.
- Delete** Delete the number.

Dialed calls

Enter the dialed calls menu to display the current record of outgoing phone list of phone numbers. Please refer to missed calls for details.

Received calls

Enter the received calls menu to display the current record has been received mobile phone number list. Please refer to missed calls for details.

All calls

Enter the all call menu, will display the all calls list. Please refer to missed calls for details.

Delete call logs

Press the LSK to select "OK" to enter sub-menu to delete call records.

Call timers

See SIM 1 and SIM 2 call timers.

Call settings

Call waiting

Open this feature, during the call if the new call, the network will notify you. Specific use with your network provider.

- **Activate** launch the function.
- **Deactivate** Close the function.
- **Query status** Query the function's status.

Call divert

Network Call Transfer service allows you to call a business case in a default transferred to a phone number you specify. The features include: Divert all voice calls, Divert if unreachable, Divert if no answer, Divert if busy, Divert all data calls.

Advanced settings

Auto redial:

Through on / off settings, to activate or disable the feature. Turned on and when your phone call after another failed attempt to connect up to redial 10 times. This feature can save you the trouble of repeated calls.

Call time reminder:

Off Close the function.

Single Enter any numbers between 1-3000 (sec) ,remind one time.

Periodic Enter any number between 30-60 (sec) , from the input time (in seconds), remind for periodic.

Answer mode:

Any key: You can press any key to answer incoming call

Auto answer when headset mode: Incoming call could be auto answered when headset mode.

Messages

Make sure that the information in writing before the message center number is set correctly. Access to an information menu, you can edit the SMS message.

Write message

Edit SMS message contents.

Inbox

To show all the messages which are received.

Drafts

To show all the saved draft messages.

Outbox

To show all the SMS which are not sent successfully.

Sent messages

To show all the SMS which are sent successfully.

Message settings

SIM1\SIM2	This menu can set SMSC address, delivery report, reply path and voicemail server function.
Memory status:	View the SIM and Phone capacity information.
Text msg. counter:	Received message and sent message counter of SIM1/SIM2.
Save sent message:	You can set it on or off.
Preferred storage:	Can set preferred storage as SIM or phone.

Multimedia

Camera

The phone includes camera, you can take pictures anytime, anywhere, and to save the photos to your phone or memory card.

State in the preview, press the LSK to enter "Options" you can do this to conduct a more detailed set of parameters.

Switch to video recorder:	Switch to the video recorder.
Photos:	shows the current list of files.
Camera settings:	Including anti-flicker, scene mode, white balance and delay timer.
Image settings:	To choose the image size and quality.
Effect settings:	Select the Effect to match your needs.
Storage:	Select the location to save the photo.
Restore default:	Set all parameters to default settings.

Image viewer

You can easily view stored in the camera album picture list, and press the LSK to enter to "Options" to choose the pictures to do the View, Send, Use as, Rename, Delete, change Storage and check Image information operations. View pictures, by pressing on the left and right navigation buttons to switch pictures.

Video recorder

Switch to camera:	Switch to the camera.
Camcorder settings:	You may change the setting of Anti-flicker, Night Mode and EV..
Video settings:	Select to change the Video quality.
Storage:	Select the location to save the Video.

Video player

You can easily view the saved video player in the video list, press the LSK to enter "Options" to select the video files to do the play, send(send the video via BT) ,rename and delete etc .

Audio player

Play the local music which stored in the memory card/phone memory.

Sound recorder

In the sound recorder interface press option will show the option below:

New record	Select to start a new record, press stop to save it .
List	List the Audio record on the phone/ memory card.
Settings	Mau change the storage location and audio quality.

FM radio

Press the OK key to turn on/ off the FM, adjuse the volume by pressing the * and # key. Press the left soft key "Options" can show FM options menu, the contents as follow:

Channel list:	Shows FM channel list.
Manual input:	Allow the user to enter the channel frequency manually, the effective value of 87.5 ~108.0.
Auto search:	Auto search FM channels.
Settings:	You can set background and loudspeaker play.
Record:	Record current FM channel.
File list:	Record file list.

Organizer

Calendar

Enter calendar the screen will show a calendar month with the current date marked. Press the up, down, left, and right navigation keys to change the date, calendar information on the screen will be updated accordingly. Press the left soft key "Options" option to display the calendar menu.

Calculator

Your phone provides you with the basic arithmetic operations. Press the left soft key "Clear", Press the right softkey "Back" to exit the calculator.

Alarm

Select and edit an alarm clock: You can set the setting of alarm on / off, Time, Repeat and Alarm tone. You can choose to set to repeat: Once, everyday, Custom.

Settings

User Profiles

Profiles including General, Silent, Meeting, Outdoor and Headset. First, based on the current scene, select a different profile, then you only need a personal profile can be set and activated.

General: General environment.

Silent: For Silent environment.

Meeting: Vibrate mode.

Outdoor: For outdoor activities, need to pre-set (for example, ring volume can be set to a higher state).

Press the left soft key "Options":

Activate: Enable the selected profile.

Ring type: You can choose repeat and beep once.

Ringtone: User can choose the preloaded audio or use their own audio file as for the ringtone.

Ringtone volume:	You can use the up and down key to adjust the ringtone volume level in this interface..
Message	Set ringtones according to their preferences.
Message volume	You can use the up and down key to adjust the ringtone volume level in this interface
Keypad	Set keypad as silent or not.
Keypad volume	Set keypad volume in this interface.
Power on	Set the ringtone for power on.
Power off	Set the ringtone for power off.
System alert:	Set it on or off.

Phone settings

You can make the following settings inside the phone setting interface:

Time and Date

You can change the phone time and date settings in this menu.

Schedule power on/off

You can set the time of powering on/off automatically.

Language

Phone supports different kinds of language for you to select. Set the current language type, then menu and interface will refresh for the corresponding language.

Pref. input method

The phone supports different kinds of methods, to choose an input method as the default when the initial input.

Display

Wallpaper:	Set wallpaper.
Screen auto lock:	Set screen auto lock time.
Power on display:	Set power on display.
Power off display:	Set screen auto lock time.
Show date and time:	You can set On/off.

Dedicated keys

Set direction key for shortcuts.

Auto update time& date

Set the device could updaten Date& Time automatically or not..

Flight mode

Switch between normal mode and flight mode. If you switch to Flight mode, all the wireless communication would close until you switch it off.

Misc. settings

LCD backlight

You can set the brightness and backlight time in this interface.

Security settings

Into the "Security Settings" menu, you can set the phone's security options, mobile phone or SIM card to avoid unauthorized use.

SIM security

PIN lock: You can set PIN lock on or off by inputting SIM PIN. And you can change PIN and PIN2.

Phone security

Phone lock: You can set it on/off.

Change password:

Change the phone password, enter the old password and then enter a new password. Phone default password is 1122.

Network settings

SIM1/SIM2:

Network selection (Automatic/Manual)

GPRS connection (When needed/Always)

GPRS transfer pref.: Data prefer/Call prefer

Connectivity

Data connection SIM: SIM1/SIM2

Data accounts: You can set data accounts of SIM1/SIM2.

BT

Power: Turn On/ Off BT.

Visibility: You can set it on/off.

My device: You can search for nearby BT devices.

Search audio device: Search BT audio device only.

My name: BT device name which can be renamed.

Advanced Options:

Audio path Leave in phone/Forward to BT headset.

Storage To receive the file will be automatically transferred to the specified path, the path can be set as phone or memory card.

My address BT address.

Restore settings

You need to input the password for the restore setting. Once you confirm, the phone would reboot and the device would reset all the setting to default .The default password is 1122.

Internet

Internet service

Homepage Browser the homepage.

Bookmarks Choose and browser the bookmarks you save.

Search or input URL Input the URL and browser it.

Settings You can change the internet setting.

SKT

Insert the SIM card, will show STK, if not insert the SIM card does not display this menu.

Facebook

You can login facebook in fun and game interface.

Twitter

You can login twitter in fun and game interface.